

GETTING THE MOST OUT OF YOUR
CORKBO™



So as not to strain one bow limb more than the other, draw the bow with two fingers, and set the string securely into the groove. Avoid depressing the trigger while cocking, as otherwise the string will not securely rest in the groove. Dry firing (shooting without projectile) is not recommended.

Some crossbows have higher shooting speeds than others; note, however, that higher speed does not always mean increased accuracy, especially with wine corks. Matched corks—of the same size, weight, dimension, and type—yield superior accuracy. For most consistent results, use matched artificial corks.

As mentioned, an ideal shooting range is 20-25 feet; when shooting at closer range, especially when your target is a hard object, beware of bounce back. Some of our favorite targets include stacked beer cans, pots and pans, action figures, images of politicians, and, of course, the gong included in the optional presentation box available from CORKBO; good backstops include couches, curtains, tapestries, and such. And if you aren't already, now is the time to start saving wine corks!

CORKBŌ 
CROSSBOWS FOR THE CONNOISSEUR